

How to upgrade the Firmware for LT-8000GT device

***Confirm the current Firmware version.

Turn on your device, on the main menu, go to Setting >> About >> check the AP versions
Firmware Version----0.0X.XX

There are 3 methods to upgrade your device's Firmware as below. Select one of methods and follow the steps to upgrade them accordingly.

1. Download the latest Firmware File from website, and upgrade it via USB cable.

Step1. Turn OFF the device and connect to the USB port of the computer. LT-8000GT will enter MASS STORAGE automatically.

Step2. Extract the downloaded Firmware "8000GT.qst" and save to it under the root directory of the LT-8000GT.

Step3. Remove the device safely: "Eject QSTARZ Mass Storage".

Step4. It will start upgrading the Firmware automatically.

Step5. Check the device's current version at Setting >> About >> AP Version, and make sure it is the latest Firmware version.

2. Use Wi-Fi to upgrade the Firmware via QRacing APP.

Step1. Turn on your device, on the main menu, go to WIRELESS to turn on Wi-Fi.

Step2. Open QRacing APP, go to Racer and Tap Connect to Connect Wi-Fi Network.

Step3. Enter SSID and Password to connect your LT-8000GT.

Step4. Click "i" symbol and click "Update" button to update Firmware.

Step5. After the file transfer is completed, restart the LT-8000GT to update the Firmware.

Step6. Check the device's current version at Setting >> About >> AP Version, and make sure it is the latest Firmware version.

3. Upgrade the Firmware/Font via QRacing PC software.

Step1. Turn OFF the device and connect to the USB port of the computer. LT-8000GT will enter MASS STORAGE automatically.

Step2. Open QRacing PC software, go to Help/Check Update.

Step3. When there is a newer Firmware version of device is available, Click "Yes" to download the file to LT-8000GT.

Step4. Remove the device safely: "Eject QSTARZ Mass Storage"

Step5. It will start upgrading the Firmware automatically.

Step6. Check the device's current version at Setting >> About >> AP Version, and make sure it is the latest Firmware version.

如何更新 LT-8000GT 設備的韌體

***如何確認機器韌體版本

於主畫面進入「設定」>>「關於」>>檢視相關韌體版本
韌體版本----0.0X.XX

有 3 種方法可以更新設備的韌體，如下所示。選擇一種方法並按照步驟進行升級。

1. 從網站下載最新的韌體檔案，並透過 USB 線更新

步驟 1: 將機器關機，連接到電腦的 USB 接口。機器將會自動進入 MASS STORAGE。

步驟 2: 將下載的韌體 8000GT.qst 複製到機器的根目錄下。

步驟 3: 選擇「安全移除裝置」，機器將會自動更新。

步驟 4: 開機後，進入「設定」>>「關於」>> 韌體版本>確認韌體版本為目前最新版本。

2. 使用 Wi-Fi 透過 QRacing APP 更新韌體

步驟 1: 開啟您的 LT-8000GT，在主畫面上，到 WIRELESS 內開啟 Wi-Fi。

步驟 2: 開啟 QRacing APP，進入車手/連結“連接網路”。

步驟 3: 輸入 SSID 和密碼以連接 LT-8000GT。

步驟 4: 點擊“i”符號並點擊“更新”按鈕以更新韌體。

步驟 5: 檔案傳輸完成後，重新啟動 8000GT 將會自動更新韌體。

步驟 6: 開機後，進入「設定」>>「關於」>> 韌體版本>確認韌體版本為目前最新版本。

3. 透過 QRacing PC 軟體更新韌體

步驟 1: 將機器關機，連接到電腦的 USB 接口。機器將會自動進入 MASS STORAGE。

步驟 2: 開啟 QRacing PC 軟體，到說明/檢查更新。

步驟 3: 當有新的韌體版本可更新時，點擊“是”將檔案下載到 LT-8000GT。

步驟 4: 選擇「安全移除裝置」，機器將會自動更新。

步驟 5: 開機後，進入「設定」>>「關於」>> 韌體版本>確認韌體版本為目前最新版本。

LT-8000GT デバイスのファームウェアをアップグレードする方法

***現在のファームウェア/フォントのバージョンを確認してください。

デバイスの電源を入れ、メインメニューで [設定] >> [バージョン情報] >> AP のバージョンを確認します。

ファームウェアバージョン----0.0X.XX

デバイスのファームウェアをアップグレードするには、以下の 3 つの方法があります。いずれかの方法を選択し、手順に従ってアップグレードしてください。

1. Web サイトから最新のファームウェア ファイルをダウンロードし、USB ケーブル経由でアップグレードします。

ステップ 1. デバイスの電源を切り、コンピュータの USB ポートに接続します。 LT-8000GT が参戦マスストレージを自動的に。

ステップ 2. ダウンロードしたファームウェア「8000GT.qst」を解凍し、LT-8000GT のルートディレクトリに保存します。

ステップ 3. デバイスを安全に取り外します: 「Eject QSTARZ Mass Storage」。

ステップ 4. ファームウェアのアップグレードが自動的に開始されます。

ステップ 5. [設定] >> [情報] >> [AP バージョン] でデバイスの現在のバージョンを確認します、最新のファームウェアバージョンであることを確認します。

2. Wi-Fi を使用して、QRacing APP 経由でファームウェアをアップグレードします。

ステップ 1. デバイスの電源を入れ、メインメニューで [ワイヤレス] に移動して Wi-Fi をオンにします。

ステップ 2. QRacing アプリを開き、Racer に移動し、[接続] をタップして Wi-Fi ネットワークに接続します。

ステップ 3. SSID とパスワードを入力して LT-8000GT を接続します。

ステップ 4. 「i」記号をクリックし、「更新」ボタンをクリックしてファームウェアを更新します。

ステップ 5. ファイル転送が完了したら、8000GT を再起動してファームウェアを更新します。

ステップ 6. [設定] >> [情報] >> [AP バージョン] でデバイスの現在のバージョンを確認します、最新のファームウェアバージョンであることを確認します。

3. QRacing PC ソフトウェアを介してファームウェア/フォントをアップグレードします。

ステップ 1. デバイスの電源を切り、コンピュータの USB ポートに接続します。 LT_8000GT が参戦マスストレージを自動的に。

- ステップ 2. QRacing PC ソフトウェアを開き、[ヘルプ]/[アップデートの確認] に移動します。
- ステップ 3. デバイスの新しいファームウェア バージョンが利用可能な場合は、[はい] をクリックしてファイルを LT-8000GT にダウンロードします。
- ステップ 4. デバイスを安全に取り外します: 「QSTARZ Mass Storage の取り出し」
- ステップ 5. ファームウェアのアップグレードが自動的に開始されます。
- ステップ 6. [設定] >> [情報] >> [AP バージョン] でデバイスの現在のバージョンを確認します、最新のファームウェアバージョンであることを確認します。