



How to upgrade the Boot for LT-9000S device

***Confirm the current Boot version.

Turn on your device, on the main menu, go to Setting >> About >> check the Boot versions

Boot Version----0.00.XX

There are 2 methods to upgrade your device's Boot as below. Select one of methods and follow the steps to upgrade them accordingly.

1. Download the latest Boot File from website, and upgrade it via USB cable.

Step 1. Turn OFF the device and connect to the USB port of the computer. LT-9000S will enter MASS STORAGE automatically.

Step 2. Extract the downloaded Boot file "9000S.qbl" and save to it under the root directory of the LT-9000S.

Step 3. Remove the device safely: "Eject QSTARZ Mass Storage".

Step 4. Power on LT-9000S, and go to Setting > Select Update Boot > Press Enter to manually update Boot.

Step 5. Check the device's current version at Setting >> About >> Boot Version, and make sure it is the latest Boot version.

2. Upgrade the Boot via QRacing PC software.

Step 1. Turn OFF the device and connect to the USB port of the computer. LT-9000S will enter MASS STORAGE automatically.

Step 2. Open QRacing PC software, go to Update / Update device firmware.

Step 3. When there is a newer Boot version of device is available, click "Yes" to download the file to LT-9000S.

Step 4. Remove the device safely: "Eject QSTARZ Mass Storage"

Step 5. Power on LT-9000S, and go to Setting > Select Update Boot > Press Enter to manually update Boot.

Step 6. Check the device's current version at Setting >> About >> Boot Version, and make sure it is the latest Boot version.



LT-9000S デバイスの Boot をアップグレードする方法

***現在の Boot バージョンを確認します。

デバイスの電源を入れ、メイン メニューで [設定] >> [バージョン情報] >> [ブート バージョン] を確認します。

Boot バージョン----0.00.XX

デバイスの Boot をアップグレードするには、以下の 2 つの方法があります。いずれかの方法を選択し、手順に従ってアップグレードしてください。

1. Web サイトから最新の Boot ファイルをダウンロードし、USB ケーブル経由でアップグレードします。

ステップ 1. デバイスの電源を切り、コンピュータの USB ポートに接続します。LT-9000S は自動的に MASS STORAGE に入ります。

ステップ 2. ダウンロードした Boot ファイル「9000S.qbl」を解凍し、LT-9000S のルート ディレクトリに保存します。

ステップ 3. デバイスを安全に取り外します: 「QSTARZ Mass Storage の取り出し」。

ステップ 4. LT-9000S の電源を入れ、[設定] > [Boot を更新する] を選択 > [Enter] を押して Boot を手動で更新します。

ステップ 5. [設定] >> [情報] >> [Boot バージョン] でデバイスの現在のバージョンを確認し、最新の Boot バージョンであることを確認します。

2. QRacing PC ソフトウェアを介して Boot をアップグレードします。

ステップ 1. デバイスの電源を切り、コンピュータの USB ポートに接続します。LT-9000S は自動的に MASS STORAGE に入ります。

ステップ 2. QRacing PC ソフトウェアを開き、デバイス ファームウェアの更新 / 更新に移動します。

ステップ 3. デバイスの新しいブート バージョンが利用可能になったら、[はい] をクリックしてファイルを LT-9000S にダウンロードします。

ステップ 4. デバイスを安全に取り外す: 「QSTARZ Mass Storage の取り出し」

ステップ 5. LT-9000S の電源を入れ、[設定] > [Boot を更新する] を選択 > [Enter] を押して手動で Boot を更新します。

ステップ 6. [設定] >> [情報] >> [Boot バージョン] でデバイスの現在のバージョンを確認し、最新の Boot バージョンであることを確認します。



如何更新 LT-9000S 設備的 Boot

***如何確認機器 Boot 版本

於主畫面進入「設定」>>「關於」>> 檢視相關 Boot 版本

Boot 版本----0.00.XX

有 2 種方法可以更新設備的 Boot，如下所示。選擇一種方法並按照步驟進行升級。

1. 從網站下載最新的 Boot 檔案，並透過 USB 線更新。

步驟 1: 將機器關機，連接到電腦的 USB 接口。機器將會自動進入 MASS STORAGE。

步驟 2: 將下載的 Boot 檔案「9000S.qbl」複製到機器的根目錄下。

步驟 3: 選擇「安全移除裝置」。

步驟 4: 將 LT-9000S 開機，進入設定 > 選擇更新 Boot > 按 Enter 鍵以手動更新 Boot。

步驟 5: 進入「設定」>>「關於」>> Boot 版本 > 確認 Boot 版本為目前最新版本。

2. 透過 QRacing PC 軟體更新 Boot。

步驟 1: 將機器關機，連接到電腦的 USB 接口。機器將會自動進入 MASS STORAGE。

步驟 2: 開啟 QRacing PC 軟體，到說明/檢查更新。

步驟 3: 當有新的 Boot 版本可更新時，點擊“是”將檔案下載到 LT-9000S。

步驟 4: 選擇「安全移除裝置」，將 LT-9000S 開機，進入設定 > 選擇更新 Boot > 按 Enter 鍵以手動更新 Boot。

步驟 5: 進入「設定」>>「關於」>> Boot 版本 > 確認 Boot 版本為目前最新版本。